Analytical Considerations for the Determination of Beryllium on Air Filters and Surface Smears Using High Throughput Automated Fluorescence

Thomas J. Oatts

B&W Y-12, Y-12 National Security Complex Oak Ridge, TN 37831-8189

Beryllium Health & Safety Committee Meeting
DOE Headquarters, Washington DC
March 16, 2010





Disclaimer

References to specific manufacturer's products or processes does not constitute or imply endorsement, or recommendation, by the United States Government, or any agency or subcontractor thereof.

The views and opinions of the author do not necessarily state or reflect those of the United States Government, or any agency or subcontractor thereof.



 Large sample loads (up to 60,000 samples/year)



- Large sample loads (up to 50,000 samples/year) at some DOE sites
- Fast sample turnaround times (< 4 hours)



- Large sample loads (up to 50,000 samples/year) at some DOE sites
- Fast sample turnaround times (< 4 hours)
- Automation



- Large sample loads (up to 50,000 samples/year) at some DOE sites
- Fast sample turnaround times (< 4 hours)
- Automation
- Instrumentation and analysis costs



Fluorescence method background

Approved methods:

- ASTM D7202
- NIOSH 7704
- NIOSH 9110

Basic methods designed for field use, or small sample load.

Methods utilize manual, sequential sample analysis approach.



Other analysis methods

- ICP-OES
- ICP-MS
- Graphite furnace AAS

These techniques also employ a sequential sample analysis approach:

Sample#1...Sample#2...Sample#3...



Automated Fluorescence

- Utilizes robotic liquid handling system and microplate reader instrument.
- Analysis of 96 well plate possible in < 3 minutes.
- Excellent detection limits (MDL=0.00079 μg/wipe)
- Large analytical range (0.01μg 20 μg)
- Highly specific for beryllium, few analytical interferences



QC - an interesting situation

- The well plate reader instrument approach created a need for an alternative approach to run level quality control.
- Existing lab instrumentation and methods are sequentially based, i.e. one sample at a time covering long periods of time (3-5 hours).
- Instrument drift is a primary concern and frequent calibration verification standards are employed by most methods to verify the standardization on an ongoing basis.



QC – automated fluorescence approach

- Full tray of 96 samples read in less than 3 minutes.
- Calibration drift is not a concern.
- Design a QC protocol to verify fitness of use, while maximizing instrument efficiency and productivity.
- Follow guidance from AIHA and A2LA lab accreditation checklists.



QC protocol for automated fluorescence

- Initial calibration verification (ICV) using a second source standard
- Blank level checking: calibration (CCB) and method blanks
- Reporting limit verification
- Duplicate lab controls (aqueous or BeO)
- Method precision from LCS duplicates
- End-of-plate calibration verification (CCV)



96 well plate layout - QC

	1	2	3	4	5	6	7	8	9	10	11	12
Α	Blank	Blank	ICV									
В	Std #1	Std #5	ICB									
С	Std #2	Std #6	RLV									
D	Std #3	Std #7	Well left empty									
E	Blank	Blank	Method blank#1									Method blank#2
F	Std #4	Std #8	LCS-1									LCS-2
G	Std #5	Std #9										ССВ
Н	Blank	Blank										CCV



Y-12 ICP method

Batch size = 45 air/smears

Sample digestion time = 63 minutes ICP determination time = 180 minutes Total analysis time = 243 minutes

Per sample time = 5.4 minutes/sample



Automated fluorescence method

Batch size = 70 air/smears

Sample prep time = 140 minutes
Fluorescence determination time = 2 minutes
Total analysis time = 147 minutes

Per sample time = 2.1 minutes/sample



Advantages

- Robotic liquid handling system reduces ergonomic issues with manual prep
- Instrumentation requires little maintenance
- Allows very large batches for increased capacity
- 4-tip system: 400 samples/8 hr shift
- Decreased turnaround time by about 50%
- Overall analytical costs decrease from ICP method



Acknowledgements

Kenn White

Kevin Ashley, PhD

Mike Brisson

Tom Ford

Larissa Welch

Dale Haste

